

Product Name: **Projector for Mirror Balls**

Product Code: **SPMB**

<u>Specification</u>	<u>Content</u>	<u>Required</u>
Size: (approx.) Ø 8.5x18cm	1 x Projector	Suitable fixings and tools for mounting
Weight (approx.) 0.4kgs	1 x Adaptor	
Material: ABS+ Metal	1 x Blue Disc	
LED: 1 non – replaceable LED	1 x Red Disc	
Bulb Rating: 3W	1 x Green Disc	
Adaptor power Input: AC 100-240V ~ 50/60Hz	1 x Yellow Disc	
Adaptor power Output: DC 5V 1A		

WARNING!


This is not a toy. Contains small parts, potentially may cause choking hazard, keep away from children. To be used for visual entertainment only.

Safety Warnings:

- Before using, ensure the product is not damaged. If any part of the product is damaged, do not attempt to use.
- This product contains non-replaceable LEDs. If any of the LEDs cease functioning, the whole unit must be disposed of according to your local council guidelines.
- Never look directly into the light source.
- Keep away from heat sources or naked flame.
- Do not use outdoors, or in damp conditions. Suitable to use indoors only.
- Ensure cable is placed such that it does not cause a trip or strangulation hazard.
- Do not attach any additional objects to this device.
- Ensure that the device is completely free standing when it is in operation and not blocked or covered by anything.
- This product is not intended for ambient lighting and is suitable only for effect lighting.
- When not in use unplug from the mains and store in safe place, away from children.

Instructions:

- 1) Before you start, please read these instructions carefully and retain for future reference. Check the contents inside the packaging and ensure you have all the required parts listed and there are no missing parts. Please contact the supplier if you have any missing parts.
- 2) This device must only be installed by a competent adult.
- 3) The projector can be mounted on a selected location using the appropriate screw and wall anchors that will secure into your wall. You can hang your spotlight via the 10mm hole in the stand on the device.
- 4) Connect the adaptor jack to the DC port of the projector.
- 5) When switched on from the mains the projector will turn on.
- 6) Colour lens can be changed from the slot found in front of the projector.



5-6 Agecroft Trading Estate, Langley Road, Salford Manchester M6 6JD

Tel: +44 161 737 5099 Website: www.play-learn.co.uk

Help & Support: help@play-learn.co.uk

Page 1 of 2